

MIYOTA

INSTRUCTION MANUAL FOR MIYOTA MOVEMENT

*How to set time and date:

For 2415, 2405, 2353

- Date ----- Pull out crown to the 1st Click Position, then:
turn crown counter-clockwise for Date adjustment
- Time ----- Pull out crown to the 2nd Click Position and
turn crown until the time is set correctly

For 2405

- Day ----- Pull out crown to the 1st Click Position, then:
turn crown clockwise for Day adjustment

